

Wizard 4 Wizard 4U

User Manual

Wireless AV & BYOD Content Sharing and Collaboration System

Wireless media presentation system supporting BYOD
for use in conferences and training rooms

Thank you for purchasing this product

This product is designed with the professional AV installers in mind. The many extensive features assist in system integration, validation and maintenance.

Installation precautions

This product has special circuitry to protect it against moderate surges and static discharges. However, to ensure reliable operation and long service life, it is important to take the necessary precautions against any spikes, surges and static discharges.

Place the unit away from heat sources and allow adequate ventilation.

Shielded cable and in particular cat6, cat6a or cat7 is highly recommended. As much as possible cables should be routed away from any noisy sources and avoiding long runs in close proximity to AC mains cables.

Thank you for purchasing this product	2
Installation precautions	2
Features	6
Package Contents	6
Wizard 4	6
Wizard 4U	6
Connectors and Controls	7
Front	7
Wizard 4	7
Wizard 4U	7
Rear	7
Wizard 4	7
Wizard 4U	8
Top SY Decal	8
Using this Product	8
Required connections	8
Optional connections	8
The Home Screen	9
Additional Options	9
SY Wands	9
Pairing with the Wand	9
Streaming from PC, Laptop or Android devices	10
BUILT-IN WEB INTERFACE	12
Navigation Icons	14
Network settings – Wireless Settings	15
Network settings – Ethernet	16
Network settings – Auto change password	17
Display & Audio – HDMI	17
HDMI Resolution	17
HDMI CEC	18
Control Base by the Display	18
Control Display Base by Base	18
Display & Audio – Audio	18
Display & Audio – Airplay screen quality	19

Display & Audio – Start screen	19
Display & Audio – Home screen background image	20
Moderator control – Moderator control	20
Moderator control – Multiview Layout	21
System settings – Buttons	21
System Settings – Date&Time	22
System Settings – Auto standby	24
System Settings – Language	25
System settings – Reset	25
System settings – Configuration file	25
System settings – Serial port settings	27
System settings – Telnet switch	27
System settings – Reboot	28
SPECIFICATIONS	33
General	33
Environmental	33
Physical	33
Troubleshooting	33
Safety Instructions	35
After Sales Service	35



The Wizard 4 and Wizard 4U are BYOD wireless/LAN presentation system designed for use where sharing and collaboration is required, such as in conferences or training rooms. Attendees can bring their own devices and connect to the Wizard device and have their image displayed. BYOD devices include Android and iPhone smart phones, and iPads.

There are two wireless wands, SY-WAND-H and SY-WAND-U, which allow wireless connections of either an HDMI source or a USB-C source as inputs to the Wizard device. These Wands must first be paired with the respective Wizard device before use.

A maximum of sixteen wireless sources can connect to the Wizard 4 or Wizard 4U but only a maximum of four can be viewed on the display, a sidebar menu allows the selection of which input signals can be displayed. The first four wireless/LAN signals that arrive are automatically assigned to the display windows and to the sidebar menu, subsequent signals are added to the sidebar menu. A mouse will be required to select the additional inputs.

Features

- Pure wireless presentation experience
- Bring Your Own Device (BYOD), no messy or unsightly cables
- Connect USB devices such as cameras, microphones, or speakers
- Fully compatible with mainstream VC platforms such as Zoom, WebEx, etc.
- Wireless content up to 1080p60
- Output HDMI 2.0 signals up to 4K60 4:4:4
- Supports native wireless mirroring protocols such as Airplay, Miracast, Chromecast
- Wireless dongles for HDMI sources and USB-C video
- PoE support on LAN port 2 only
- RS232 control
- Built-in WebGUI for configuration and moderator control

Package Contents

Wizard 4

- 1x Wizard 4
- 2x Wi-Fi antennas
- 1x 12V DC PSU
- 1x Manual

Wizard 4U

- 1x Wizard 4U
- 3x Wi-Fi antennas
- 1x 12V DC PSU
- 1x Manual

Connectors and Controls

Front

Wizard 4




Wizard 4U



Name	Description
USB 2.0	USB 2.0 port for USB devices
USB-C	USB-C port for USB-C devices
POWER	Power switch


Rear

Wizard 4



Name	Description
ANT	Wi-Fi antenna connection
LINE OUT	Audio output
USB 3.0	USB 3.0 Type A port
RESET	Reset button (recessed)
HDMI 2.0	HDMI output to display
RS232	RS232 control port
LAN 1	LAN port 1
LAN 2	LAN port 2 with PoE support
DC 12V/3A	PSU input
ANT	Wi-Fi antenna connection

Wizard 4U



Name	Description
ANT	Wi-Fi antenna connection
LINE OUT	Audio output
RS232	RS232 control port
K	Slot for Kensington lock
USB 3.0 Port 1	USB 3.0 Type C port
USB 3.0 Ports 2~4	USB 3.0 Type A ports
ANT	Wi-Fi antenna connection
HDMI 2.0	HDMI output to display
LAN 1	LAN port 1
LAN 2	LAN port 2 with PoE support
DC 12V/3A	PSU input
ANT	Wi-Fi antenna connection

Top SY Decal

On the top of the Wizard 4 and the Wizard 4U is an SY decal that lights with different colours depending on the status of the unit:

Decal Colour	Description – The Wizard device is:
Off	Not powered up
Flashing Red	Booting after being powered up
Solid Red	In stand-by mode, press the POWER button to activate the Wizard unit
Green	Not connected to any input source
Blue	Connected to at least one input source

Using this Product

Required connections

1. Connect a display device to the HDMI output.
2. Attach the antennas to the rear of the Wizard unit.
3. Connect the 12V DC PSU to the PSU input port.

Optional connections

1. Connect a LAN cable to either or both the LAN ports.
2. Connect an RS232 cable to the 3-way RS232 connector.
3. Connect a 3.5mm stereo jack connector to the audio output.
4. Attach any USB devices, such as a mouse to access to the on-screen menu system.

The Home Screen

The Home screen is always displayed when there are no input sources, or when all active input sources have been stopped from the sidebar menu.



The Home screen provides the following information:

- The device ID: Wizard 4 or Wizard 4U
- The current password for BYOD sources, this may change depending on the setting on the 'Auto change password' option in the 'Network setting' tab of the built-in WebGUI.
- The current time – Configured on the 'Date & Time' settings in the 'System Settings' tab of the built-in WebGUI.
- The upper half of the middle section shows how to connect casting devices to the Wizard.
- The lower half of the middle section shows how to connect laptops and PCs to the Wizard using one of the two SY Wand units.
- The bottom shows the WiFi IP address of the Wizard unit and the LAN IP address for LAN port 1 and LAN port 2 respectively. N/A indicates that the IP address for that port is Not Available. This will be different if DHCP is enabled.

Additional Options

SY Wands

SY-WAND-H HDMI wireless wand to connect an HDMI source to the Wizard device. A USB port is required to power the SY-WAND-H.

SY-WAND-C USB-C wireless wand to connect a USB-C video source to the Wizard device. Power is taken from the USB-C output port.

Pairing with the Wand

To use either of these Wands, it must first be paired with the same Wizard device it is being used with. To perform the Wand pairing do the following:

1. Plug the SY-WAND-H into the USB-A port, or the SY-WAND-C into the USB-C port on the front of the Wizard device.
2. Wait for the pairing process to complete and then unplug the wand and connect it to

the source device. The SY-WAND-H requires a separate USB-A port act as its power supply source.

3. Wait for the indicator on the Wand to stop flashing and then touch the wand to begin sending the video to the Wizard device.

Once paired, the Wand will always connect to the same Wizard device. Pairing will need to be repeated should the Wand need to work with a different Wizard device.

On-Screen drawing and Whiteboard Modes

These are two separate features of the Wizard

Streaming from PC, Laptop, or Android

Use the Built-In Web Interface to download the WirelessMedia app appropriate to your system. Run the downloaded app to install WirelessMedia on your computer system.


The WirelessMedia app will stream a secondary video display to the Wizard device using either WiFi or LAN connections. This will allow you to continue using your primary display.

Note that any IP addresses shown in this section are examples only, the IP of your Wizard device will be shown instead.


Open the WirelessMedia app from the WirelessMedia icon:



The app will then search for and list all Wizard devices that are visible to the PC, laptop, or Android device:




Click the Connect button to the right of the Wizard device and the password enter window will appear:



Enter the eight-digit password as displayed on the Home page of the Wizard unit, including any leading zeros. Click OK to complete the connection.

If you are prompted to download a newer version of the WirelessMedia app, use the Built-In Web Interface to obtain the latest version appropriate to your computer system.

Once connected, the following screen will appear:







When you are ready to being sharing your screen, click on the **Ready to share** button. The screen will now change to:




Click the **Sharing** button to stop sharing with the Wizard unit.

Above the Sharing button is a row of icons:

	Display a list of detected Wizard devices
	Settings – see below
	Toggle between split screen and full screen.
	


Settings

Selecting the settings icon will display the available optional settings:




Any active item is indicated by a filled green box.

Setting	Default State	Description
Extended Screen	Off	Toggle between streaming the secondary (desktop extend) or primary display
Keep Aspect Ratio	On	Toggle between maintaining the aspect ratio of the streamed display or stretching the image to fit.
Lowest Latency (mouse)	On	Change the mouse latency, lowest when enabled.
Stream Mode	Quality Priority	Select between Fluency Priority and Quality Priority. This setting will depend on the quality of the network connection.
Volume	100%	Set the output volume level for any sounds sent from the computer.

Click the  button in the top right corner to close the WirelessMedia app. A confirmation box will appear, click the **Yes** button to end the session.


Built-In Web Interface

The Wizard 4 and Wizard 4U devices have a built-in Web GUI interface for changing the setting and configuration of the Wizard unit. Use the Home screen to get the IP address for the LAN port you wish to use and the download page will appear:



This page provides several buttons to download the Wizard streaming software package for various platforms and for accessing the User Manual.

To access the configurations settings pages, click on the twin gear icon at the top right and the login page will appear:




Enter the current password and click the **Login** button.

The default login password is: **admin**

Settings Page

After entering the password the **Settings** page will appear with the **Network settings** tab already opened to the **Wireless network** section.



The sidebar menu selects the respective settings page, each detailed in the following sections. Any settings already in progress will not be lost if a different page is selected.

Navigation Icons

The two icons on the right of the top bar are:


Home – Return to the Downloads page, select the twin gears to return to the above Network settings page.

Logout – Return to the login page.

Network settings – Wireless Settings

The Start Modifying button will initiate a four step process to change the settings for the wireless network identify of the Wizard device:


1. Device Name – Enter a new device name to clearly identify the Wizard device on the wireless network.



Click **Next step** to go to step 2.

Click **Cancel** to abort this settings mode.


2. Mode selection – Choose one of the wireless operating modes.



Click **Next step** to go to step 3.

Click **Previous** to go back to step 1.

3. Network settings – Choose one of the options for the internet access mode.



The dropdown boxes have the following settings:


- SSIS Discovery and connection Yes or No Default is Yes
- Frequency 2.4GHz or 5GHz Default is 5GHz

- Channel 36, 40, 44, 48, 149, 153, 157, 161 Default is 36
- Password This is the same as shown on the HDMI Home page

Click **Next step** to go to step 4.

Click **Previous** to go back to step 2.

4. SSID setting – If needed, enter the GUEST and/or STAFF network SSID.




Click **Submit setting** to confirm any changes made.

Click **Previous** to go back to step 3.

Network settings – Ethernet

Select LAN 1 or LAN 2 from the top tab selectors as desired:



DHCP – select Enable or Disable as needed. When DHCP is set as Enable, the remaining edit boxes are not usable.

IP Address – Set the static IP address for the Wizard LAN port.

Mask – Set the network subnet mask for the Wizard LAN port.

Gateway – Set the IP address of the default Gateway device.

DNS1 – Set the IP address for the first domain name server.


DNS2 – Set the IP address for the second domain name server.

MAC – The MAC address of the Wizard device, this cannot be changed.

Click the **Confirm settings** button to set the changes into the Wizard device.

Network settings – Auto change password


This is the access password for wireless BYOD devices, to change the login password see_. This pages sets how often this password is changed from one of the following: Never, 5 minutes, 30 minutes, 1 hour, 2 hour, 4 hour, or 24 hour. The interval chosen will take effect immediately and will be acknowledged by a green Success banner at the bottom of the browser window.



Display & Audio – HDMI


HDMI Resolution

Select the desired output resolution, or Auto to allow the Wizard to automatically choose the best output resolution for the display device. The selected option will take effect immediately and will be acknowledged by a green **Success** banner at the bottom of the browser window.



Only resolutions that the connected HDMI display device supports will be listed

HDMI CEC



This page sets the CEC power mode options:

Control Base by the Display


- ON – when the CEC enabled display device is turned off the Wizard will also turn off
- OFF – turning off of the CEC enabled display device will not turn off the Wizard device.

Control Display Base by Base

- ON – when Wizard device turns off it will also turn off the CEC enabled display device.
- OFF – the Wizard device will not turn off the display device.

The default state is with both options set to OFF.

Display & Audio – Audio



From the dropdown list, select where the audio is to be output:

Jack – this is the LINE OUT analogue audio output on the rear of the Wizard device. In this mode there is no HDMI audio to the display device.


HDMI – the HDMI output carries the audio. In this mode there is no analogue audio on the LINE OUT connector.

Jack&HDMI – Both the HDMI output and the LINE OUT carry the audio signal.

USB – This will only appear if USB speakers are connected to the Wizard device. In this mode the audio signal is sent only to the USDB speakers.

The audio volume slider sets the maximum output volume level for the Wizard device.

Display & Audio – Airplay screen quality




Select the resolution for Apple AirPlay signals:

HIGH	1920x1080
MEDIUM	1600x900
LOW	1280x720


The selected option will take effect immediately and will be acknowledged by a green Success banner at the bottom of the browser window.

Display & Audio – Start screen



These options select what information is displayed on the Home, or Start, screen of the Wizard device.

Display & Audio – Home screen background image




The left icon opens a file browser to choose a new image for the Home screen.

The middle icon(s) allow the deletion of existing images.

The large + icon allow more images to be loaded.

Moderator control – Moderator control

The Moderator control section controls the appearance of the sidebar menu on the HDMI display:



To use the moderator options a mouse must be connected to the Wizard unit to access the sidebar to select which preview images in the HDMI output sidebar list are presented to the display. A maximum of four images are allowed at any time.

The options are:


Hide side bar completely (including arrow)

Small menu (no preview windows)

Large menu (show preview windows)


Moderator control – Multiview Layout

Select one of the 11 multiview layout views for the HDMI output:




System settings – Buttons

The Connected and Paired tabs show the details of the currently Connected SY Wand units (Buttons) and the history of any SY Wand units that were previously used with the Wizard device. Note that the actual details given will differ for each installation.



The Operate column shows a red Pause icon for active SY Wands and a green play icon for SY Wands that are not currently sending to the Wizard unit. Click on the respective icon to change the state of the selected SY Wand.



This is a list of any SY Wand that was paired with the Wizard unit at any time in the past. To remove items from the list either use the left side check boxes to select the item to remove and then click the red Delete button, or click on the Trash bin icon to remove an individual item. Be careful when using this last option as the entries are immediately deleted with no confirmation window.

System Settings – Date&Time


The **Date and Time** tab has one dropdown box with the following options:

Automatic date & time


Use network-provided time

Off


Click the **Confirm settings** button to accept the new option.




When the Automatic date & time of set to Off, the following screen will appear:



Enter the date and time in the respective boxes. To aid in entering the date and time values, a selection pop-up will appear below the respective edit box:



The date picker




The time selector

As shown above, the date format is entered in ISO 8601 format: YYYY-MM-DD.


For the time selector panel, note that the seconds will wrap over to the minutes, and the minutes will wrap over to the hours.

The **Time Zone** tab is used to adjust the time and date display to your locale. Select your time zone from the dropdown list:




System Settings – Auto standby

This page is used to set the duration of inactivity after which the Wizard will automatically enter its standby mode.




System Settings – Language




This page changes the language of the overlay items on the Home screen, any text that is part of the background image will not be changed.

System settings – Reset



Use this page to reset all configurable options to the factory defaults. Clicking the Confirm settings button will bring up a confirmation box:




Click **OK** to restore the Wizard to factory default settings.

Click **Cancel** to keep current settings.


System settings – Configuration file

There are two tabs, Upload configuration and Download configuration. The configuration file, named config.dat, is a binary image of the current configuration of the Wizard unit. This can be

used to restore a last known good configuration file to the Wizard unit, provided that it was previously downloaded, to replace a bad or faulty configuration.



Click **Select file** to choose the desired **config.dat** file.



Click the **Download** button to save the current configuration of the Wizard unit to the binary image file 'config.dat'. The actual download location depends on the web browser settings.

System settings – Serial port settings

The screenshot shows the 'Serial port setting' page. On the left is a navigation menu with 'System settings' selected. The main content area is titled 'Serial port Setting' and contains several configuration options, each with a dropdown menu:

- Enable serial: **Enable**
- Baud rate: **115200**
- Parity: **NONE**
- Flow control: **NONE**
- Serial port function: **Uart function as telnet**
- Data bits: **8**
- Stop bits: **1**

A blue 'Confirm settings' button is located at the bottom right of the configuration area.

This page configures the RS232 serial port options (**bold** items are the factory defaults):

Enable serial: **Enabled** / Disabled
Baud Rate: 1800, 2400, 4800, 9600, 19200, 38400, 57600, **115200**
Parity: **NONE**, EVEN, ODD
Flow control: **NONE**, XON/XOFF
Serial port function: **UART function as telnet** / UART function commander
Data bits: 5, 6, 7, **8**
Stop bits: **1**, 2

The **UART function as telnet** option requires a Telnet session to send RS232 commands.

The **UART function commander** option accepts direct RS232 commands.

Click the Confirm settings to accept any changes. The green **Success** banner will appear at the bottom of the browser window.

System settings – Telnet switch

This page is used to enable or disable the telnet option.

The screenshot shows the 'Telnet switch' page. On the left is a navigation menu with 'System settings' selected. The main content area is titled 'Telnet switch' and contains a single configuration option:

- Enable telnet:

Clicking the selection box causes the green **Success** banner to appear at the bottom of the

browser window to confirm the new setting.

System settings – Reboot

When the Enable option is set, the Day options are used to set the days, with a time in when the Wizard device shall automatically reboot. Click the **Submit** button to set any changes to the options. Click the **Reboot now** button to reboot the Wizard device immediately.

The screenshot shows the 'Timing reboot' configuration page. On the left is a navigation menu with categories like Network settings, Display & Audio, Moderator control, System settings, Buttons, Date & Time, Auto standby, Language, Reset, Configuration file, Serial port setting, Telnet switch, Reboot, Security settings, Firmware upgrade, Other settings, UCC-Device manager, and About device. The main content area is titled 'Timing reboot' and contains an 'Enable' checkbox, a row of checkboxes for days of the week (all checked), and a 'Reboot time' input field with '06:00'. Below this is a note: 'There may be an error between the device time and the network time. Please connect to the network before each use to automatically set the device time.' At the bottom are 'Submit' and 'Reboot now' buttons.

Security settings – Security level

The screenshot shows the 'Security level' configuration page. The left navigation menu is the same as in the previous screenshot. The main content area is titled 'Security level' and contains a table with 13 rows of security items. Each row has a '#', a 'Security item' description, and four radio button columns: 'level 1', 'level 2', 'level 3', and 'Customize'. The 'level 1' column is selected for all items.

#	Security item	level 1	level 2	level 3	Customize
1	Dynamic code/Charge code every	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
2	Encryption of Data/Proprietary	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
3	Changing the code deletes all temporary data from Kick & Show	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
4	"Airplay" PIN code	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
5	Telnet password	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
6	Encryption of Data: AES-256 Bit + RSA-1024Bit	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
7	Password changing deletes and removes the data of the base unit	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
8	"Miracast" PIN code	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
9	Disable the android APK	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
10	Disable "Airplay"	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
11	Disable "Firmware Degrader"	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
12	Disable Miracast	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
13	Disable "Chromecast"	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>

Use the top row selection buttons to choose the desired security level setting. Use the columns to enable or disable any of the security features given in the Security item column.

Security settings – Login password

The Cancel password option will delete the login current password and enable entry to the settings pages with no password requirement.

To change the login password, enter the details as given in the edit boxes.

Click the **Confirm settings** button to accept the changes.


The default password is 'admin'. This is also the password after resetting the Wizard unit to factory defaults.

Security settings – Connection password

This option changes the format of the numerical password displayed on the Home page that allows devices to connect to the Wizard. The password format can be four leading zeros followed by a 4-digit password (0000xxxx), or an 8-digit password (xxxxxxx). The change is accepted immediately with the green **Success** banner being shown at the bottom of the browser.


Any user that wishes to connect must always enter all the 8 digits shown on the Home screen, regardless of the chosen password format.

Firmware Upgrade – Firmware update




Only use this page if a valid firmware upgrade file is available on your PC or laptop. Click the **Select firmware** button to open the default file browser for your OS. Navigate to the folder containing the firmware update file and click the **Open** to begin the update.

Firmware Upgrade – Automatic update




This option enables or disables Automatic updates via the Internet or from a local file.

Other Settings – Auto create launcher



This option determines whether the WirelessMedia software will be automatically copied to a USB memory stick when it is plugged into any of the USB ports on the Wizard device.

Other Settings – Clear history after meeting




The screenshot shows the 'Settings' application with a sidebar on the left containing various categories like Network settings, Display & Audio, Moderator control, System settings, Security settings, Firmware upgrade, and Other settings. The main content area is titled 'clear history after meeting' and features a dropdown menu currently set to 'Always'. Below the dropdown, there are three explanatory sections: 'Decide by user' (warning message), 'Never' (meeting history intact), and 'Always' (automatic clearing).

There are three options for clearing the history of any device that connected to the Wizard unit during a meeting session:

- Decide by user** When all connections, including hotspot/SSID connected devices and dongles, are disconnected from Wizard, a pop-up warning message appears to request the user if the meeting history should be erased.
- Never** When all device connections to the Wizard are disconnected, the system leaves the meeting history intact.
- Always** When all device connections to the Wizard are disconnected, the system automatically clears the history without giving a warning message.


Other Settings – Developer tools



The screenshot shows the 'Settings' application with the sidebar on the left. The main content area is titled 'Log' and contains a checkbox labeled 'Enable the maximum storage space for the system log, and automatically close it after 24 hours'. Below the checkbox is a blue button labeled 'Download system log'.


This page is for downloading a System log.

UCC-Device Manager – USB-Camera




This page lists any USB cameras available to the Wizard, choose the desired camera and a preview will be displayed. Any PC or Laptop running the WirelessMedia app will be able to view that camera by selecting the Virtual Meeting Camera in the camera app on the PC or laptop.

UCC-Device Manager – USB-Audio



Any USB connected speaker or microphone system will be listed in the respective selection boxes. The speaker and microphone level bars show the signal levels for those devices. To use USB speakers, be sure that the USB option is selected on **Display & Audio – Audio** web page detailed on page 18.

About Device – About Device



This page gives the internal model name, firmware version, Web server version and the product serial number.

Specifications

General

Source Video Format	Up to 1080p60
HDMI Output Resolutions	HDMI Output: 4K60, 4K30, 1080p60, 720p60
HDMI Standard	HDMI 2.0 for the output
HDCP Compliance	HDCP 1.4 and HDCP 2.2
LAN/Ethernet	Port 1: 100Mbps Port 2: 1000Mbps, supports PoE Default settings: Proxy: None DHCP: Enabled IP address is displayed on the Home screen
Antennas	Wizard 4: 2 Wizard 4U: 3
Audio input	AirPlay, Miracast, DLNA, Windows/MAC, WMH, USB, BT SpeakPhone
Analogue audio output	3.5mm stereo jack
USB interfaces	Wizard 4: Front – 1x USB 2.0 & 1x USB C, Rear – 1x USB 3.0 Wizard 4U: Front – 1x USB 2.0 & 1x USB C, Rear – 1x USB-C, 3x USB 3.0
RS232	1x 3-way pluggable terminal connector
Number of simultaneous windows	Up to 4 on display screen Up to 14 in thumb nail list
Number of simultaneous connection	Up to 16
Wireless data rate	Up to 1200 Mbps
Latency	< 100ms, 20ms minimum
Wi-Fi Transmission Protocol	WIFI IEEE 802.11 a/g/n/ac
Wi-Fi Frequency Band	2.4 GHz & 5 GHz
PoE Standard	IEEE 802.3f
Power Supply	12V DC or PoE
Power Consumption	10W max.

Environmental

Storage Temperature	-20°C ~ 60°C (-4°F ~ 140°F)
Operating Temperature	0°C ~ 40°C (32°F ~ 104°F)
Operating Humidity	20 ~ 90 %RH (non-condensing)

Physical

Dimensions (WxHxD)	220 x 120 x 41 mm
Weight	1 kg

Troubleshooting

Problem	Cause	Solution
“WirelessMedia for Android” app running on Android device, or Airplay on iOS device, cannot find the Wizard base unit	Wi-Fi password of base unit changed when Android or iOS device is connected to the base unit using Wi-Fi	Reconnect the Android or iOS device and enter the new password displayed on the Wizard home screen
Poor image quality on the main display	The cable between the Wizard and the display is	<ul style="list-style-type: none">• Try another cable• Replace the cable

Problem	Cause	Solution
	<p>either of poor quality or too long</p> <p>Wrong output resolution</p>	<ul style="list-style-type: none"> Check that the cable connectors are fitting properly in the HDMI connectors <p>Change the Wizard output resolution to match the preferred resolution of the display.</p>
Bad wireless connection	<p>Wi-Fi problems</p> <ul style="list-style-type: none"> RF Interference Channel over used <p>The Wizard device does not automatically jump to other channels</p>	<p>Use a Wi-Fi scanner to find a free Wi-Fi channel and select it using the configuration settings. Regularly check the RF environment to determine if there are frequent changes in Wi-Fi networks your area</p>
Low signal strength	<ul style="list-style-type: none"> Metal cabinets, walls, building construction ... causing reflections and harming the Wi-Fi signal Obstacles between the Wand and the Wizard unit reducing the Wi-Fi strength and quality 	<ul style="list-style-type: none"> Place the Wizard unit nearer to the display Change the orientation of the antennas in relation to the sender direction Remove or limit as many obstructions as possible between the Wizard device and transmitter
The “WirelessMedia” app doesn’t start when the Wand is connected to a laptop computer	<ul style="list-style-type: none"> When using for the first time, the Launcher app must be installed on the laptop 	<ul style="list-style-type: none"> After installing the Launcher program, “WirelessMedia” is ready to use at any time

Safety Instructions

To ensure reliable operation of this product as well as protecting the safety of any person using or handling these devices while powered, please observe the following instructions.

1. **ONLY USE** the power supply provided. If an alternate supply is required, check the voltage, polarity and that it has sufficient power to supply the device it is connected to.
2. **DO NOT** operate this product outside the specified temperature and humidity range given in the above specifications.
3. Ensure there is adequate ventilation as this product generates heat while operating.
4. Repair of this product should only be carried out by qualified professionals as this product contains sensitive devices that may be damaged by any mistreatment.
5. Only use this product indoors and in a dry environment. **DO NOT** allow any liquids or harmful chemicals to come into contact with this product.

After Sales Service

1. Should you experience any problems while using this product, firstly refer to the Troubleshooting section in this manual and/or your local dealer before contacting SY Technical Support.
2. When calling SY Technical Support, please provide the following information:
 - Full Product Name and Model Number
 - Product Serial Number
 - Details of the fault and any conditions under which the fault occurs.
3. This product has a two year standard warranty beginning from the date of purchase as stated on the sales invoice. For full details please refer to our Terms and Conditions.
4. The SY Product warranty is automatically void under any of the following conditions:
 - The product is already outside of its warranty period
 - Damage to the product due to incorrect usage or storage
 - Damage caused by unauthorised repairs
 - Damage caused by mistreatment of the product
5. Please direct any questions or problems you may have to your local dealer before contacting SY Electronics.